Control stations and enclosures
Plastic control stations XAL D and XAL K
For Harmony® Ø 22 control and signalling units XB5

7

9
ZBE 101

9
ZBV ●●

9
ZBE 102

10
ZB5 AZ009

8
ZEN L1111

8
ZEN L1121

8
ZEN L1121

8
ZEN L1121

8
ZAL V●●

8
ZEN L1121

11
ZBZ 32

SIS-Label

12

1
ZB5 AA333

1
ZB5 AP3S

2
ZB5 AL434

3
ZB5 AS54

3
ZB5 AS14

4
ZB5 AD203

4
ZB5 AG0

5
ZB5 AV033

6
ZB5 AW358

Schneider Electric

version: 6.3

36030-EN.indd

Control stations and enclosures
Plastic control stations XAL D and XAL K
For Harmony® Ø 22 control and signalling units XB5

XAL D and XAL K control stations are available in two forms:
■ Complete.
■ For customer assembly
These control stations use the plastic bezel pushbuttons, switches and pilot lights of the Harmony XB5 range, which offers a wide choice of circular and square types of head.

Complete stations

Pre-assembled
These are complete, ready to install, stations fitted with 1 to 3 buttons to cater for the most commonly encountered functions:
■ **Start or Stop,** with:
□ 1 flush spring return pushbutton,
□ 1 red, spring return, mushroom head pushbutton.
■ **Emergency stop or Emergency switching off,** with:
□ 1 red, latching, mushroom head pushbutton **3** (standard or trigger action), either push-pull or turn to release, with or without key.
■ **Start-Stop,** with:
□ 2 flush spring return pushbuttons,
□ 1 flush spring return pushbutton **1** + 1 projecting spring return pushbutton **2**,
□ 1 2-position selector switch **4** + 1 pilot light with integral red LED, if required.
■ **Two functions,** with:
□ 2 flush spring return pushbuttons **1**.
■ **Three functions,** with:
□ 3 flush spring return pushbuttons **1**,
□ 2 flush spring return pushbuttons **1** + 1 projecting spring return pushbutton **2**,
□ 2 flush spring return pushbuttons **1** + 1 red, latching, mushroom head pushbutton **3**.
These pushbuttons, switches and pilot lights comprise plastic heads from the Harmony XB5 range and electrical blocks (contact or light) **8** that are mounted in the back of the enclosure.

Stations for customer assembly

For customer assembly
These stations are for assembly by the user and offer a choice of 2 assembly methods:
■ **Box method**
Identical to the pre-assembled versions. The electrical blocks **8** are mounted on a metal mounting plate in the back of the enclosure **7**.
■ **Station method**
The electrical blocks **9** are mounted directly beneath the heads using a body/fixing collar **10**.

It is possible to assemble stations with 1 to 5 heads, each of which can be combined with 3 electrical blocks **8** or **9** (contact or light).

The XAL range offers a wide choice of head types for:
■ Spring return pushbuttons **1** or **2**, either marked or unmarked.
■ Spring return mushroom head pushbuttons.
■ Latching mushroom head pushbuttons **3**.
■ Selector switches with standard or long handle and key switches **4**.
■ Toggle switches.
■ Pilot lights **5**.
■ Illuminated spring return pushbuttons **6**.
■ Illuminated selector switches with standard handle **4**.

Accessories

For heads
Markings can be customised by using legend holders **11** which can either be fitted with pre-marked legends or legends engraved by the user. Alternatively, paper legends (protected), prepared using "SIS Label" software **12**, or peel-off legends (supplied on sheet for marking by laser printer) can be used.